OPERATOR'S MANUAL FOR AirVANTAGE™ TwoHAND™ 10,000 RPM 8 in. (200 mm) RANDOM ORBITAL SANDERS



Declaration of conformity AirVANTAGE™ Tools AirVANTAGE™ Tools 10018 Lower Azusa Road, Unit #C; El Monte, California 91731 USA declare on our sole responsibility that the products 8 in. TwoHAND™ Random Orbital Sanders (See "Product Configuration/Specifications" Table for particular Model) to which this declara- tion relates is in conformity with the following standard(s) or other normative document(s) EN ISO 15744:2008. Following the provisions of 89/392/EEC as amended by 91/368/EEC & 93/44/EEC 93/68/EEC Directives and consolidating Directive 2006/42/EC 08.01.2012, Taiwan Peter Wu					
Place and date of issue Name Signature or equivalent marking of authorized person					
Operator Instructions Includes – Please Read and Comply, F Warranty, Product Configuration and S Parts Page, Parts List, Work Stations, Service, Operating Instructions and Cc Back-Up Pads, Service Tools and Acc Service Kit, Spare Part Kits, Service In	Important Read these instructions care- fully before installing, operating, servicing or repairing this tool. Keep these instructions in a safe accessible location.				
Manufacturer/Supplier AirVANTAGE™ Tools 10018 Lower Azusa Road; Unit #C; El Monte, California 91731 USA Tel: (626)-575-4968 Fax: (626)-575-4968	Required Personal Safety Equipment Safety Glasses Breathing Masks Safety Gloves Ear Protection				
Recommended Airline Size - Minimum 10 mm 3/8 in	Air Pressure Hose Length Maximum Working Pressure 6.2 bar 90 psig 8 meters 25 feet Recommended Minimum NA NA				e 2 bar 90 psig NA NA

Please Read and Comply with:

- 1) General Industry Safety & Health Regulations, Part 1910, OSHA 2206, available from: Superintendent of Documents; Government Printing Office; Washington DC 20402
- Safety Code for Portable Air Tools, ANSI B186.1 available from: American National Standards Institute, Inc.; 1430 Broadway; New York, New York 10018
- 3) State and Local Regulations.

Proper Use of Tool

This sander is designed for sanding all types of materials i.e. metals, wood, stone, plastics, etc. using abrasive designed for this purpose. Do not use this sander for any other purpose than that specified without consulting the manufacturer or the manufacturer's authorized supplier.

Do not use back-up pads that have a working speed less than 10,000 RPM free speed. Never use back-up pads that have a weight and/or size different than the machine was specifically designed for.

AirVANTAGE[™] Warranty

All AirVANTAGE[™] TwoHAND[™] Random Orbital Sanders are warranted for defects in materials or workmanship for one year from the date of delivery to the user. Combined with the AirVANTAGE[™] name, this Warranty expresses our total confidence in the superior quality, durability, and performance of the AirVANTAGE[™] LP. To receive any expressed or implied warranty, tool must be repaired by an authorized AirVANTAGE[™] Service Center. The "Service Instructions" section in this document is provided for use after completion of the warranty period. To receive warranty, tools must be operated under the conditions as described in the "Putting the Tools into Service" section of this document and be connected to an air supply system as shown in Figure 1. Tools that have been exposed to extreme conditions will be covered under warranty at the sole discretion of AirVANTAGE[™]

Parts Page



Parts List

Item No.	Part No.	Description	Qty.
1	AVA0040	EXTERNAL RETAINING RING	1
2	AVA0021	BEARING	1
3	AVB0017	REAR ENDPLATE	1
4	AVA0042	O-RING	1
5	AVA0441	CYLINDER ASSEMBLY	1
6	AVA0445	VANE	5
7	AV/B0118	ROTOR	1
8	AVA0041	KEY	2
0	AV/R0016		1
10	AVD0010		1
10	AVA0019		1
10	AVA0045		1
12	AVA0001		1
13	AVA2541	FRONT BEARING DUST SHIELD	1
14	AVB0444	MOTOR SHAFT	1
15	AVA1711	THREADED PLUG	2
16	AVB0376	RH HOUSING	1
17	AVA0032	MUFFLER INSERT	1
18	AVA1218	TOP HOUSING SEAL	1
19	AVB0290	MOTOR HOUSING SEAL	1
20	AVA0655	VALVE STEM ASSEMBLY	1
21	AVA0015	VALVE SLEEVE	1
22	AVA2585	5.0 mm (3/16 in.) ORBIT SAFETY LEVER ASSEMBLY	1
23	AVA0004	CYLINDER SPRING PIN	1
24	AVA1865	SPACER RING	OPT
25	AVB0420	HANGER	OPT
20	AVB0420		1
20	AVD0050		1
27	AVD0050		
20	AVA2379		0
29	AVA1902	8 In. ROS PAD MODINI	1
30	AVA2559	DOUBLE ROW BEARING	1
31	AVA2560	SPACER	1
32	AVA2581	SPINDLE BEARING DUST SHIELD	1
33	AVA1875	BELLEVILLE RETAINER	1
34	AVA1980	BALANCER	1
35	AVA0078	SCREW	1
36	NA	8 in. PAD	1
37	AVA0009	VALVE SEAT	1
38	AVA0007	VALVE	1
39	AVA0014	VALVE SPRING	1
40	AVA0730	AIRLINE SEAL ASSEMBLY	1
41	AVA0500	EXHAUST GASKET	1
42	AVB0181	SGV EXHAUST NOZZLE (SGV Machines)	1
43	AVB0182	NV/CV FXHALIST NOZZI F (NV & CV Machines)	1
44	AVA0664	SCREW	7
45	AVA0517	EXHALIST TUBING (NV & CV Machines)	1
46	AV/A0516		1
47	Δ\/Δ0511		
4/	AVA0011		
40	AVA 1920		
49	AVG0210		E I
DU E4	AVA 1398		2
51	AVA 1430		
52	AVB0183	SPEED CONTROL	
53	AVA0043	U-KING	1
54	AVA0039	IN I ERNAL RETAINING RING	1
55	AVA0510	INLET CAPTIVE RING	1
56	AVA0509	O-RING	1
57	AVA0628	O-RING (NV & CV Machines)	1
58	AVA0776	MUFFLER (NV & CV Machines)	2
59	AVA0731	INLET/EXHAUST END CAP ASSEMBLY (NV Machines)	1
60	AVA1294	INLET/EXHAUST END CAP ASSEMBLY (SGV & CV Machines)	1
61	AVA0013	INLET BUSHING ASSEMBLY	1
		Ø 28 mm (1 in.) VACUUM HOSE TO Ø 28 mm (1 in.) x 38 mm (1 1/2 in.) ADAPTOR COUPLING &	
62	AVA0392	AIRLINE ASSEMBLY (CV Machines)	1
63	AVA0623	Ø 28 mm (1 in) HOSE SEAL (SGV Machines)	1
		Ø 28 mm (1 in) VACHI IM HOSE TO DOUBLE RAG FITTING AND AIRI INF ASSEMBLY (SGV Ma	<u> </u>
64	AVA0412	chines)	1
65	AV/A0469		1
00	AVA0400		
00	AVA0470		
0/	AVA0123		
68	AVA0076		4
69	AVA2665	1-ZU TURA WRENCH	1

Product Configuration/Specifications: 10,000 RPM Random Orbital Sander

Orbit	Pad Face	Vacuum Type	Pad Type	Pad Size inch (mm)	Model Number	Product Net Weight pounds (kg)	Height inch (mm)	Length inch (mm)	Power HP (watts)	Air Consumption scfm (LPM)	*Noise Level dBA	**Vibra- tion Level m/s ²	**Uncertainty Factor ²
3/16 in. (5.0 mm) Hook		Non-Vac	Low Profile	(8) 200	082078	3.34 (1.52)	4.98 (126.6)	12.27 (311.6)	0.46 (343)	23 (651)	TBD	TBD	TBD
	Hook	Central Vacuum			082103	3.42 (1.56)	4.98 (126.6)	13.87 (352.2)	0.46 (343)	23 (651)	77	4.87	0.98
		Self- Gen. Vacuum			082128	3.41 (1.55)	4.98 (126.6)	13.87 (352.2)	0.46 (343)	23 (651)	TBD	TBD	TBD

The noise test is carried out in accordance with EN ISO 15744:2008 - Hand-held non-electric power tools -- Noise measurement code -- Engineering method (grade 2).

The vibration test is carried out in accordance with ISO 28927-3:2009. Hand-held portable power tools – Test method for evaluation of vibration emission – . Part 3: Polishers and rotary, orbital and random orbital sanders.

Specifications subject to change without prior notice.

*The values stated in the table are from laboratory testing in conformity with stated codes and standards and are not sufficient for risk evaluation. Values measured in a particular work place may be different than the declared values. The actual exposure values and amount of risk or harm experienced to an individual is unique to each situation and depends upon the surrounding environment, the way in which the individual works, the particular material being worked, work station design as well as upon the exposure time and the physical condition of the user. AirVANTAGE Tools. cannot be held responsible for the consequences of using declared values instead of actual exposure values for any individual risk assessment.

Further occupational health and safety information can be obtained from the following websites: http://europe.osha.eu.int (Europe) http://www.osha.gov (USA)

Work Stations

The tool is intended to be operated as a hand held tool. It is always recommended that the tool be used when standing on a solid floor. It can be in any position but before any such use, the operator must be in a secure position having a firm grip and footing and be aware that the sander can develop a torque reaction. See the section "Operating Instructions".

Putting the Tool into Service

Use a clean lubricated air supply that will give a measured air pressure at the tool of 90 psig (6.2 bar) when the tool is running with the lever fully depressed. It is recommended to use an approved 3/8 in. (10 mm) x 25 ft (8 m) maximum length airline. It is recommended that the tool be connected to the air supply as shown in Figure 1.

Do not connect the tool to the airline system without incorporating an easy to reach and operate air shut off valve. The air supply should be lubricated. It is strongly recommended that an air filter, regulator and lubricator (FRL) be used as shown in Figure 1 as this will supply clean, lubricated air at the correct pressure to the tool. Details of such equipment can be obtained from your supplier. If such equipment is not used then the tool should be manually lubricated

To manually lubricate the tool, disconnect the airline and put 2 to 3 drops of suitable pneumatic motor lubricating oil such as Fuji Kosan FK-20, Mobil ALMO 525 or Shell TORCULA® 32 into the hose end (inlet) of the machine. Reconnect tool to the air supply and run tool slowly for a few seconds to allow air to circulate the oil. If the tool is used frequently, lubricate it on a daily basis or lubricate it if the tool starts to slow or lose power.

It is recommended that the air pressure at the tool be 90 PSI (6.2 Bar) while the tool is running so the maximum RPM is not exceeded. The tool can be run at lower pressures but should never be run higher than 90 PSI (6.2 Bar). If run at lower pressure the performance of the tool is reduced.

Operating Instructions

- Read all instructions before using this tool. All operators must be fully trained in its use and aware of these safety rules. All service and repair must be carried out by trained personnel.
- Make sure the tool is disconnected from the air supply. Select a suitable abrasive and secure it to the back-up pad. Be careful and center the abrasive on the back-up pad.
- Always wear required safety equipment when using this tool.
- 4) When sanding always place the tool on the work then start the tool. Always remove the tool from the work before stopping. This will prevent gouging of the work due to excess speed of the abrasive.
- Always remove the air supply to the sander before fitting, adjusting or removing the abrasive or back-up pad.
- Always adopt a firm footing and/or position and be aware of torque reaction developed by the sander.
- Use only correct spare parts.
- Always ensure that the material to be sanded is firmly fixed to prevent its movement.
- 9) Check hose and fittings regularly for wear. Do not carry the tool by its hose; always be careful to prevent the tool from being started when carrying the tool with the air supply connected.
- 10) Dust can be highly combustible. Vacuum dust collection bag should be cleaned or replaced daily. Cleaning or replacing of bag also assures optimum performance.
- 11) Do not exceed maximum recommended air pressure. Use safety equipment as recommended.
- 12) The tool is not electrically insulated. Do not use where there is a possibility of coming into contact with live electricity, gas pipes, water pipes, etc. Check the area of operation before operation.

- 13) Take care to avoid entanglement with the moving parts of the tool with clothing, ties, hair, cleaning rags, etc. If entangled, it will cause the body to be pulled towards the work and moving parts of the machine and can be very dangerous.
- 14) Keep hands clear of the spinning pad during use.
- 15) If the tool appears to malfunction, remove from use immediately and arrange for service and repair.
- 16) Do not allow the tool to free speed without taking precautions to protect any persons or objects from the loss of the abrasive or pad.



AirVANTAGE™ Back-Up Pads

AirVANTAGE™ back-up pads are perfectly mated for use on the AirVANTAGE™ LP. Constructed from premium, industrial-quality materials and featuring a riveted fiberglass and steel hub with molded urethane, their durability and precise construction are the ideal complement to the performance of the AirVANTAGE™ LP. See "Product Configuration/Specifications" Table for the correct replacement pad for a particular model.

Description	Dort #
Description	Part #
8 in. low profile, non-vacuum, vinyl face	1285400
8 in. low profile, non-vacuum, hook face	1285401
8 in. low profile, vacuum, vinyl face	1285410
8 in. low profile, vacuum, hook face	1285411
8 in. low profile, screen vacuum, hook face	1285441

SERVICE INSTRUCTIONS FOR AirVANTAGE™ 10,000 RPM TwoHAND™ 8 in. (200 mm) RANDOM ORBITAL SANDERS



AirVANTAGE™ Service Tools and Accessories

When an AirVANTAGE[™] TwoHAND[™] ROS needs to be serviced, we offer a tool kit to make the disassembly/assembly fast and easy. The Service Tools are highly recommended for use with the Overhaul Service Kit. NOTICE: To receive any expressed or implied warranty, the tool must be repaired by an authorized AirVANTAGE[™] Service Center. The 8 in. Random Orbital Sanders Service Instructions section provided are for use after completion of the warranty period.



AirVANTAGE™ Overhaul Service Kit

The AVB0578 AirVANTAGE™ Overhaul Service Kit contains all the replacement parts that naturally wear over time and a straightforward manual to make servicing an AirVANTAGE™ sander simple. Overhauling the Random Orbital Sander can be made even easier with the use of the above Service Tools. The Service Tools also reduce the chance of improper assembly.

AVB0578 Overhaul Service Kit for 10,000 RPM TwoHAND™ 8 in. ROS Contents			
Part No.	Description	Qty.	
AVA0040	External Retaining Ring	1	
AVA0021	Bearing	1	
AVA0042	O-Ring	1	
AVA0445	Vanes	5	
AVB0118	Rotor	1	
AVA0041	Кеу	2	
AVA0019	Bearing	1	
AVA0032	Muffler Insert	1	
AVA0655	Valve Stem Assembly	1	
AVA2559	Bearing	1	
AVA2560	Spacer	1	
AVA2581	Spindle Bearing Dust Shield	1	
AVA0009	Valve Seat	1	
AVA0007	Valve	1	
AVA0014	Valve Spring	1	
AVA0730	Airline Seal Assembly	1	
AVA0500	Exhaust Gasket	1	
AVA0043	O-Ring	1	
AVA0039	Internal Retaining Ring	1	
AVA0628	O-Ring	1	
AVA0776	Muffler	2	
AVA2674	8 in. TwoHand ROS Instructions	1	

Sander Spare Parts Kits







Muffler Kit Reorder P/N AVA1877

ROS Spindle Bearing Kit Reorder P/N AVA2676

Air Inlet Kit Reorder P/N AVA1879







Endplate Bearing Kit Reorder P/N AVA0614 Speed Valve Kit Reorder P/N AVA1880 Rotor, Vanes and Key Kit Reorder P/N AVA1881

10,000 RPM – TwoHAND™ 8 in. (200 mm) LOW PROFILE RANDOM ORBITAL SANDERS SERVICE INSTRUCTIONS

NOTICE: To receive any expressed or implied warranty, tool must be repaired by an authorized service center. The following general service instructions provided are for use after completion of the warranty period.

DISASSEMBLY INSTRUCTIONS

Motor Disassembly:

To prevent damage to the motor assembly the following sequence must be followed:

- 1. Open up the access hole in the Shroud.
- 2. Remove the Pad by removing the Screws using a T-20 Torx® driver.
- 3. Remove the Balance Lobe by removing the Screw.
- 4. Remove the pad mount assembly by pulling it away from the tool.
- Remove the Belleville Retainer by removing the Screws using a 2.5mm HEX. L wrench.
- 6. Remove the Spindle Bearing Dust Shield and Spacer. Discard the Spindle Bearing Dust Shield.
- 7. Remove the Bearing from pad mount.
- Unscrew the Lock Ring with the T-6 Motor Lock Ring Wrench/Spindle Puller Tool. The motor assembly and Lock Ring can now be lifted out of the Motor Housing.
- 9. Remove the Retaining Ring and the O-Ring from the Cylinder.
- Remove the Rear Endplate. This requires supporting the Rear Endplate using a Bearing Separator and lightly pressing the shaft through the Bearing and the Rear Endplate.
- 11. Remove the Cylinder and the five Vanes and Rotor from the Shaft Balancer.
- 12. Remove the Keys and then press off the Front Endplate (with Bearing), O-Ring and the Lock Ring. It may be necessary to remove the Bearing with a Bearing Separator if it came out of the Front Endplate and stuck to the shaft of the Shaft Balancer.
- 13. Remove the Front Bearing Dust Shield from the shaft of the Shaft Balancer. Discard the Front Bearing Dust Shield.
- 14. Remove the bearing(s) from the endplates by using the T-8 Bearing Removal Tool to press out the bearings.

Housing Disassembly:

- 1. Unscrew the threaded Plug(s) and/or the Handle (if used) from the Motor Housing.
- 2. Remove the Hanger and Spacer Ring. (if used)
- Remove the Retaining Ring. The Speed Control (with O-Ring) will now pull straight out from the Motor Housing. Use an o-ring pick to remove the O-Ring from the Speed Control.
- 4. Use a T-20 Torx driver to unscrew all Screws.
- 5. Remove the Housings.
- 6. Remove the Muffler and Seals from the Housing.

- 7a. For Non-Vacuum (NV) machines: Remove the End Cap.
- 7b. For Central Vacuum (CV) and Self Generated Vacuum (SGV) machines: Remove the End Cap. Remove the Hose Seal from the CV/SGV End Cap.
- Unscrew the Inlet Bushing from the End Cap. Remove the Mufflers, Captive Ring, O-Ring, and O-Ring from the End Cap.
- 9a. For NV and CV machines: Remove the exhaust Tubing, Tubing Clamp, and inlet Tubing from the motor housing assembly. Separate the exhaust Tubing, Tubing Clamp, and inlet Tubing from each other.
- 9b. For SGV machines: Remove the inlet Tubing from the motor housing assembly.
- Unscrew the three Screws from the motor housing assembly.
- 11a.For NV and CV machines: Remove the NV/CV Exhaust Nozzle and the Gasket from the motor housing assembly.
- 11b.For SGV machines: Remove the SGV Exhaust Nozzle and the Gasket from the motor housing assembly.
- 12. Press out the Spring Pin from the Motor Housing and remove the Safety Throttle Lever.
- Remove the Seal Assembly. This component can become damaged during removal and will need to be replaced if damaged.
- Remove the Spring, Valve, Valve Seat, and the Valve Stem from the Motor Housing. Use an o-ring pick to remove the o-ring from the Valve Stem.
- 15. Remove the Sleeve from the Motor Housing.
- 16. Remove the Shroud from the Motor Housing.

ASSEMBLY INSTRUCTIONS

NOTE: All assembly must be done with clean dry parts and all bearings are to be pressed in place by the correct tools and procedures as outlined by the bearing manufacturers.

Housing Assembly:

- 1. Press the Sleeve flush to the top of the Motor Housing.
- 2. Lightly grease the o-ring and place it in the groove of the Valve Stem. Install the Valve Stem into the Sleeve.
- Install the Valve Seat, the Valve and the Spring. Press the Seal Assembly into the Motor Housing.
- Install the Safety Throttle Lever into the Motor Housing with the Spring Pin.
- 5. Install the Shroud onto the Motor Housing.
- 6a. For NV and CV machines: Install the NV/CV Exhaust Nozzle and the Gasket using the three Screws. Torque

setting to be 21-30 in-lbs (2.4-3.4 N-m). Insert the exhaust Tubing and the inlet Tubing into the Tubing Clamp. Then insert the exhaust Tubing into the Exhaust Nozzle and insert the inlet Tubing into the Seal Assembly.

- 6b. For SGV machines: Install the SGV Exhaust Nozzle and Gasket using the three Screws. Torque setting to be 21-30 in-lbs (2.4-3.4 N-m). Insert the inlet Tubing into Seal Assembly.
- Install the two Mufflers, O-Ring, Captive Ring, O-Ring into the End Cap. Lightly grease the o-rings before installation.
- Coat the threads of the Bushing Assembly with 1 or 2 drops of Loctite[™] 222 or equivalent non-permanent pipe thread sealant. Screw the Bushing Assembly into the inlet port on the End Cap until hand tight. Torque setting to be 60-72 in-lbs (6.8-8.1 N-m).
- 9a. For CV and SGV machines: Insert the inlet Tubing into the End Cap. Install the Hose Seal into the End Cap.
- 9b. For NV machines: Insert the inlet Tubing into the End Cap.
- 10. Install the Muffler and Seals into the Housing.
- 11. Install the internal components into the Housing. Then install the Housing.
- Install the Screws. Torque setting to be 27- 30 in-lbs (3.0-3.4 N-m) for Screw. Torque setting to be 29- 33 in-lbs (3.3-3.7 N-m) for Screw.
- 13. Lightly grease the O-Ring and place it in the groove on the Speed Control. Insert the Speed Control into the Motor Housing in the full on position. Install the Retaining Ring. Caution: Make sure the Retaining Ring is completely snapped into groove in the Motor Housing.
- 14. Install the Spacer Ring into the Hanger. Secure the Hanger by screwing in the Plugs and/or install the optional Side Handle.

Motor Assembly:

- 1. Place a new Front Bearing Dust Shield onto the Shaft Balancer. Be sure that the Dust Shield is flat against the Shaft Balancer.
- Lightly grease the O-Ring with a light mineral grease and place it in the groove of the Lock Ring, then place it on the Shaft Balancer with the O-Ring facing towards the keyway.
- 3. Use the larger end of the T-13 Bearing Press Sleeve to press the front Bearing (with two Shields) onto the shaft of the Shaft Balancer.
- 4. Slide the Front Endplate with the bearing pocket facing down onto the motor shaft. Gently press the Front Endplate onto the Bearing using the larger end of the T-13 Bearing Press Sleeve until the front Bearing is seated in the bearing pocket of the Front Endplate. Caution: Only press just enough to seat the Bearing into the pocket. Over-pressing can damage the Bearing or Front Endplate.
- Place the two Keys into the grooves of the Shaft Balancer. Place the Rotor onto the shaft of the Shaft Balancer, making sure that it is a light slip fit.
- 6. Place the Cylinder Assembly over the Rotor with the shorter end of the spring pin in the Cylinder engaging the blind hole in the Front Endplate. Note: The spring pin must project .060 in. (1.5 mm) above the flanged side of the Cylinder. Oil the five Vanes with a quality pneumatic tool oil and place in the slots in the Rotor. One or two drops of oil should be sufficient.
- 7. Press fit the rear Bearing (two shields) into the Rear Endplate with the T-1B Bearing Press Tool. Make sure

the T-1B Press Tool is centered on the O.D. of the outer race of the Bearing. Lightly press fit the Rear Endplate and Bearing over the Shaft Balancer using the small end of the T-13 Bearing Press Sleeve. The Sleeve should press only the inner race of the Bearing. Important: The Rear Endplate and Bearing is pressed correctly when the Cylinder is squeezed just enough between the endplates to stop it from moving freely under its own weight when the motor assembly is held horizontal, but be able to slide between the Endplates with a very light force. If pressed too tightly the motor will not run freely. If the pressed assembly is too loose, the motor will not turn freely after assembly in the Motor Housing.

- 8. Secure the assembly by placing the Retaining Ring in the groove of the Shaft Balancer. Caution: The Retaining Ring must be placed so that the middle and two ends of the hoop touch the Bearing first. Both raised center portions must be securely "snapped" into the groove in the Shaft Balancer by pushing on the curved portions with a small screwdriver.
- 9. Lightly grease the O-Ring and place in the air inlet of the Cylinder Assembly.
- 10. Lightly grease or oil the inside diameter of the Motor Housing, line up the spring pin of the Cylinder Assembly with the marking on the Motor Housing and slide the Motor Assembly into the Motor Housing. Make sure the spring pin engages the pocket in the Motor Housing.
- 11. Carefully screw the Lock Ring into the Motor Housing with the T-6 Motor Lock Ring Wrench/Spindle Puller Tool. Torque settings to be 55-65 in-lbs (6.2-7.3 N-m). Note: A simple technique to assure first thread engagement is to turn the Lock Ring counter-clockwise with the T-6 Motor Lock Ring Wrench/Spindle Puller while applying light pressure. You will hear and feel a click when the lead thread of the Lock Ring drops into the lead thread of the housing.
- 12. Press the Bearing into the bore of the Pad Mount.
- 13. Take the assembly of the Pad Mount and Bearing, with the Bearing facing towards you, place the Spacer and Spindle Bearing Dust Shield on the Bearing.
- Install the Belleville Washer by screwing in Screws using a 2.5mm HEX. L wrench. Torque setting to be 21-30 in-lbs (2.4-3.4 N-m).
- 15. Install the Balance Lobe by screwing in Screw. Torque setting to be 95-105 in-Ibs (10.7-11.8 N-m).
- Place the tool on top of the Pad. Be sure that the Pad Mount is fully engaged into the studs on the Pad.
- 17. Secure the Pad to the tool by screwing in Screws using a T-20 Torx® driver. The Screws will have to be inserted thru the access hole on the outside of the Shroud. Torque setting to be 21-30 in-lbs (2.4-3.4 N-m).
- 18. Close up the access hole in the Shroud.

Testing:

Place 3 drops of quality pneumatic air tool oil directly into the motor inlet and connect the machine to a 90-psig (6.2 bar) air supply. A 10,000 RPM tool should run between 9,500 to 10,500 RPM when the air pressure is 90-psig (6.2 bar) at the inlet of the tool while the tool is running at free speed. This free speed will be about 500 rpm to 1,000 RPM less when a Vacuum or Hook Face Pad is used because of wind resistance. This will not affect performance when sanding.

Loctite® is a registered trademark of the Loctite Corp.

Troubleshooting Guide							
Symptom	Possible Cause	Solution					
	Insufficient Air Pressure	Check air line pressure at the Inlet of the Sander while the tool is running at free speed. It must be 90 psig (6.2 Bar).					
	Clogged Muffler(s)	See the "Housing Disassembly" section for Muffler removal. The Muffler can be back flushed with a clean, suitable cleaning solution until all contaminates and obstructions have been removed. If the Muffler can not be properly cleaned then replace it. Replace Muffler Insert (See the "Housing Assembly" Section).					
	Plugged Inlet Screen	Clean the Inlet Screen with a clean, suitable cleaning solution. If Screen does not come clean replace it.					
Low Power and/or Low Free Speed	One or more Worn or Broken Vanes	Install a complete set of new Vanes (all vanes must be replaced for proper operation). Coat all vanes with quality pneumatic tool oil. See "Motor Disas- sembly" and "Motor Assembly".					
	Internal air leakage in the Motor Housing indicated by higher than normal air con- sumption and lower than normal speed.	Check for proper Motor alignment and Lock Ring engagement. Check for damaged O-Ring in Lock Ring groove. Remove Motor Assembly and Re-Install the Motor Assembly. See "Motor Disas- sembly" and "Motor Assembly".					
	Motor Parts Worn	Overhaul Motor. Contact authorized Service Center.					
	Worn or broken Spindle Bearings	Replace the worn or broken Bearings. See "Motor Disassembly" and "Motor Assembly".					
Air leakage through the Speed Control and/or Valve Stem.	Dirty, broken or bent Valve Spring, Valve or Valve Seat.	Disassemble, inspect and replace wore or damaged parts. See "Housing Dis- assembly" and "Housing Assembly".					
	Incorrect Pad	Only use Pad Sizes and Weights designed for the machine.					
	Addition of interface pad or other material	Only use abrasive and/or interface designed for the machine. Do not at- tach anything to the Sanders Pad face that was not specifically designed to be used with the Pad and Sander.					
Vibration/Rough Operation	Improper lubrication or buildup of foreign debris.	Disassemble the Sander and clean in a suitable cleaning solution. Assemble the Sander.					
	Worn or broken Rear or Front Motor Bearing(s)	Replace the worn or broken Bearings. See "Motor Disassembly" and "Motor Assembly".					
	For vacuum machines it is possible to have too much vacuum while sanding on a flat surface causing the pad to stick to the sanding surface.	For SGV machines add extra washer(s) to the pad spindle to increase the gap between the pad and shroud. For CV machines reduce vacuum through the vacuum system and/or add extra washer(s) to the pad.					



AirVANTAGE™ Tools 10018 Lower Azusa Road; Unit #C; El Monte, California 91731 USA Tel: (626)-575-4568 Fax: (626)-575-4968